

S1C60N08 Manual errata

ITEM		
Object manuals	Document code	Object pages
S5U1C60N08E Manual	MF1180-02	11
<p>6.2 Differences from Actual IC</p> <p>- LCD -</p> <p>(Error)</p> <p>If the internal voltage regulator is disabled by mask option, connect VL1 to VL3 and VL2 to VL4 for driving a 1/3 bias LCD (VL1=VL3=3V, VL2=VL4=2V, VL5=1V, reference value), or connect VL1 to VL4, VL2 to VL5 and VL3 to VDD for driving a 1/2 bias LCD (VL1=VL4>VL2=VL5).</p>		
<p>(Correct)</p> <p>If the internal voltage regulator is disabled by mask option, connect VL1 to VL3 and supply the power 4.0V(3.5V)* by Vss ground, connect VL2 to VL4 and supply the power 3.0V(2.0V)* by Vss ground, supply the power 2.0V(0.5V)* by Vss ground to VL5 for driving a 1/3 bias LCD or connect VL1 to VL4 and supply the power 3.5V* by Vss ground, connect VL2 to VL5 and supply the power 2.0V* by Vss ground, VL3 to VDD for driving a 1/2 bias LCD.</p> <p>*A case of 3V LCD panel. In parentheses, a case of 4.5V LCD panel.</p>		